



$$\beta_- = \frac{R_1}{R_1 + R_2} \quad \beta_+ = \frac{R_4}{R_3 + R_4}$$

$$\text{Net } \beta = \beta_- - \beta_+$$

Required for stability:  $\beta > 0$